


PERCUSSION *Plus*

Tuning Compass


Hand instruments



PERCUSSION *Plus*

Tuning Compass

Xylophones and metallophones



PP022 / PP7022 Bass
chromatic half metallophones
PP028 / PP7028 Bass
chromatic half xylophones

C#29 - G#48

PP017 / PP7017 Soprano
diatonic metallophones
PP023 / PP7023 Soprano
diatonic xylophones

C52 - A37

PP020 / PP7020 Alto
chromatic half metallophones
PP026 / PP7026 Alto
chromatic half xylophones

C#41 - G#60

PP019 / PP7019 Alto diatonic
metallophones
PP025 / PP7025 Alto diatonic
xylophones

C40 - A61

F45 - C88

PP092 Chromatic concert xylophone

PP018 / PP7018 Soprano
chromatic half metallophones
PPP024 / PP7024 Soprano
chromatic half xylophones

C#53 - G#72

PP021 / PP7021 Bass diatonic
metallophones
PP027 / PP7027 Bass diatonic
xylophones

C28 - A49

PP088 Tenor chromatic xylophone

A37 - C64

PP089 Tenor chromatic xylophone

Bb38 - Bb62